




Eagle Pro hydraulic cylinders should be repaired only by a qualified operator or Eagle Pro Authorized Service Center. Only use Eagle Pro or other approved hydraulic oil. Always release pressure in hydraulic system and disconnect hose(s) before making repair.

### Parts List



| Item no. | Part no.     | Description                       | Quantity | Item no. | Part no.     | Description                      | Quantity |
|----------|--------------|-----------------------------------|----------|----------|--------------|----------------------------------|----------|
| 1        | 41102        | Hex Socket Cap Head Bolt (M12*40) | 1        | 11       | 11017        | Eye Ring                         | 2        |
| 2        | EDLL1502TS-1 | Washer                            | 1        | 12       | EAB-201A     | Female Coupler                   | 2        |
| 3        | 41012        | Steel Ball (10.0MM G10)           | 1        | 13       | 13114        | Socket Head Set Screw (1/16 NPT) | 4        |
| 4        | EDLL1502TS-2 | Saddle                            | 1        | 14       | EF3.1        | Safety Valve                     | 1        |
| 5        | EDLL1502TS-3 | Top Base                          | 1        | 15★      | 43690        | Piston Combination Ring B        | 1        |
| 6★       | 21158        | Gasket                            | 1        | 16       | EDLL1502TS-6 | EDLL-1502TS Lock Nut             | 1        |
| 7★       | 24161        | O-Ring                            | 1        |          | EDLL1504TS-3 | EDLL-1504TS Lock Nut             | 1        |
| 8★       | 43689        | Piston Combination Ring A         | 1        | 17       | EB205-10     | Turning Bar                      | 1        |
| 9        | EDLL1502TS-4 | EDLL-1502TS Piston                | 1        | 18       | EDLL1502TS.1 | Cribbing Ring                    | 3        |
|          | EDLL1504TS-1 | EDLL-1504TS Piston                |          | 19       | EDLL1502TS.2 | Cribbing Saddle                  | 3        |
| 10       | EDLL1502TS-5 | EDLL-1502TS Cylinder Body         | 1        |          |              |                                  |          |
|          | EDLL1504TS-2 | EDLL-1504TS Cylinder Body         |          |          |              |                                  |          |

★ Denotes items in and only available in repair kit: **EDLL1502TS-RP-0**