




Eagle Pro hydraulic cylinders should be repaired only by a qualified operator or Eagle Pro Authorized Service Center. Only use Eagle Pro or other approved hydraulic oil. Always release pressure in hydraulic system and disconnect hose(s) before making repair.

Parts List



Item no.	Part no.	Description	Quantity	Item no.	Part no.	Description	Quantity
1	41103	Hex Socket Cap Head Bolt (M12*40)	1	11	11018	Eye Ring	2
2	EDLL2502TS-1	Washer	1	12	EAB-201A	Female Coupler	2
3	41012	Steel Ball (10.0MM G10)	1	13	13114	Socket Head Set Screw (1/16 NPT)	4
4	EDLL2502TS-2	Saddle	1	14	EF3.1	Safety Valve	1
5	EDLL2502TS-3	Top Base	1	15★	43694	Piston Combination Ring B	1
6★	21204	Gasket	1	16	EDLL2502TS-6	EDLL-2502TS Lock Nut	1
7★	43024	O-Ring	1		EDLL2504TS-3	EDLL-2504TS Lock Nut	
8★	43693	Piston Combination Ring A	1	17	EB207-10	Turning Bar	1
9	EDLL2502TS-4	EDLL-2502TS Piston	1	18	EDLL-2502TS.1	Cribbing Ring	3
	EDLL2504TS-1	EDLL-2504TS Piston		19	EDLL-2502TS.2	Cribbing Saddle	3
10	EDLL2502TS-5	EDLL-2502TS Cylinder Body	1				
	EDLL2504TS-2	EDLL-2502TS Cylinder Body					

★ Denotes items in and only available in repair kit: **EDLL2502TS-RP-0**