




EAGLE PRO Cylinders should be repaired only by a qualified operator or Authorized EAGLE PRO Service Centers. Use Only EAGLE PRO or other approved hydraulic oil. Release pressure in hydraulic system and disconnect hose(s) before making repair.

Parts List



| Item No. | Part Number | Description | Qty. | Item No. | Part Number | Description | Qty. |
|----------|-------------|--------------------|------|----------|-------------|-----------------------------|------|
| 1 | ES502-4 | Thread Cover | 1 | 10 | 21668 | Anti-wear Ring | 1 |
| 2 | 13003 | Bolt | 2 | 11★ | 21393 | Gasket | 1 |
| 3 | ES502-3 | Saddle | 1 | 12★ | 24321 | Y-ring | 1 |
| 4★ | JB-d80 | Anti-wear Ring | 1 | 13 | 31061 | Spring Assembly ES-504 only | 1 |
| 5 | ES502-2 | Stop Ring | 1 | | 31064 | Spring Assembly ES-506 only | 1 |
| 6 | 21546 | Anti-wear Ring | 1 | 14 | ES504-1 | Cylinder ES-504 only | 1 |
| 7 | 11010 | Bolt | 2 | | ES506-1 | Cylinder ES-506 only | 1 |
| 8★ | QY2-13 | Copper Washer | 2 | 15 | ES504-6 | Handle ES-504 Only | 1 |
| 9 | ES504-5Y | Piston ES-504 Only | 1 | | ES506-6 | Handle ES-506 only | 1 |
| | ES506-5Y | Piston ES-506 Only | 1 | 16 | EAB-201A | Coupler | 1 |

★ Items included in Repair Kit, Repair Kit order number: **ES502-RP-B**