




EAGLE PRO Jacks should be repaired only by a qualified operator or Authorized EAGLE PRO Service Centers. Use Only EAGLE PRO or other approved hydraulic oil. Release pressure in hydraulic system and disconnect hose(s) before making repair.

Parts List



Item No.	Part Number	Description	Quantity	Item No.	Part Number	Description	Quantity
1	ETJ205-1	Handle Grip	1	25	ETJ205-25	Ball	3
2	ETJ205-2	Handle	1	26	ETJ205-26	Spring	2
3	ETJ205-3	Snap Ring	6	27	ETJ205-27	Screw	2
4	ETJ205-4	Socket	1	28	ETJ205-28	Pump Body	1
5	ETJ205-5	Pin	2	29★	ETJ205-29	O-ring	2
6	ETJ205-6	Plunger	1	30★	ETJ205-30	Y-ring	1
7★	ETJ205-7	Wiper Ring	1	31★	ETJ205-31	O-ring	1
8	ETJ205-8	Back-up Ring	2	32	ETJ205-32	Valve Stem Bush	1
9★	ETJ205-9	O-ring	2	33	ETJ205-33	Oil Pipe	1
10	ETJ205-10	Screw	1	34	ETJ205-34	Retaining Ring	1
11★	ETJ205-11	Gasket	3	35	ETJ205-35	Filter	1
12	ETJ205-12	Ball	1	36	ETJ205-36	Flexible Bag	1
13★	ETJ205-13	O-ring	1	37	ETJ205-37	Screw	1
14	ETJ205-14	Release Rod	1	38	ETJ205-38	Assemble Of Cylinder	1
15	ETJ205-15	Snap Ring	1	39	ETJ205-39	Steel Wire	1
16	ETJ205-16	Unload Handle	1	40★	ETJ205-40	O-ring	1
17	ETJ205-17	Screw	1	41	ETJ205-41	Retaining Ring	2
18	ETJ205-18	Adjusting Screw	1	42	ETJ205-42	Bush	2
19	ETJ205-19	Spring	1	43	ETJ205-43	Forked Mounting	1
20	ETJ205-20	Ball Seat	1	44★	ETJ205-44	Y-ring	1
21	ETJ205-21	Ball	1	45	ETJ205-45	Snap Ring	1
22	ETJ205-22	Linkage	1	46	ETJ205-46	Limit Block	1
23	ETJ205-23	Screw	4	47	ETJ205-47	Pillar	1
24	ETJ205-24	Pin	1	48★	ETJ205-54	D-ring	1

★ Items included in Repair Kit, Repair Kit order number: **ETJ205-RP-0**