




EAGLE PRO Jacks should be repaired only by a qualified operator or Authorized EAGLE PRO Service Centers. Use Only EAGLE PRO or other approved hydraulic oil. Release pressure in hydraulic system and disconnect hose(s) before making repair.

Parts List



Item No.	Part Number	Description	Quantity	Item No.	Part Number	Description	Quantity
1	ETJ225-1	Upper Handle	1	33	ETJ225-33	Oil Pipe	1
2	ETJ225-2	Lower Handle	1	34	ETJ205-34	Retaining Ring	1
3	ETJ205-3	Snap Ring	6	35	ETJ205-35	Filter	1
4	ETJ205-4	Socket	1	36	ETJ225-36	Spring	2
5	ETJ205-5	Pin	2	37	ETJ225-37	Screw	2
6	ETJ225-6	Plunger	1	38	ETJ205-37	Screw	2
7★	ETJ225-7	O-ring	2	39	ETJ205-25	Ball	1
8	ETJ225-8	Back-up Ring	2	40	ETJ225-40	Cylinder	1
9	ETJ225-9	Pin	1	41	ETJ225-41	Steel Wire	1
10	ETJ205-10	Screw	2	42	ETJ225-42	Retaining Ring	1
11★	ETJ205-11	Gasket	3	43	ETJ225-43	Limit Block	1
12	ETJ205-12	Ball	1	44	ETJ225-44	Retaining Ring	2
13★	ETJ205-13	O-ring	1	45	ETJ225-45	Bush	2
14	ETJ205-14	Release Rod	1	46	ETJ225-46	Forked Mounting	1
15	ETJ205-15	Snap Ring	1	47★	ETJ225-47	O-ring	1
16	ETJ205-16	Unload Handle	1	48★	ETJ225-48	Y-ring	1
17	ETJ205-17	Screw	1	49	ETJ225-49	Pillar	1
18	ETJ205-18	Adjusting Screw	1	50	ETJ225-50	Axle	2
19	ETJ205-19	Spring	1	51	ETJ225-51	Plate	2
20	ETJ205-20	Ball Seat	1	52	ETJ225-52	Spring Wash	2
21	ETJ205-21	Ball	1	53	ETJ225-53	Nut	1
22	ETJ205-22	Linkage	1	54	ETJ225-54	Retaining Ring	2
23	ETJ205-23	Screw	4	55	ETJ225-55	Wheel	2
24	ETJ205-24	Pin	1	56	ETJ225-56	Bearing	2
25	ETJ205-25	Ball	3	57	ETJ225-57	Snap Ring	2
26	ETJ205-26	Spring	2	58	ETJ225-58	Snap Ring	2
27	ETJ205-27	Screw	2	59	ETJ225-59	Spring Pin	1
28	ETJ225-28	Pump Body	1	60	ETJ225-60	Pin	1
29★	ETJ205-29	O-ring	2	61	ETJ225-61	Knob	1
30★	ETJ225-30	Y-ring	1	62	ETJ225-62	Spring	1
31★	ETJ205-31	O-ring	1	63	ETJ225-63	Axle	1
32	ETJ225-32	Valve Stem Bush	1				

★ Items included in Repair Kit, Repair Kit order number: **ETJ225-RP-0**